

**Limited Warranty:** Tub Refinishing, Inc. DBA Munro Products or Munro Bath Systems as follows; this warranty is in lieu of all other written or unwritten, expressed or implied warranties, and Tub Refinishing, Inc. DBA Munro Products or Munro Bath Systems expressly disclaims any warranty of merchantability or fitness for a particular purpose. The buyer assumes all risks whatsoever as to the use of the material. Keep away from children, animals or persons that are sensitive to paint or fumes. Fumes can be harmful to humans and animals and are can be flammablepoison.

**Safety:** A protective respirator can be worn if available. Use product with adequate ventilation. Always use rubber gloves.

Tub Refinishing, Inc DBA Munro Products or Munro Bath Systems is not responsible for accidents or misuse of these products or parts and materials of this kit. Safety is in the hands of the user. If you are unsure about the use or safety of this product please return the unopened and unused kits to the supplier. Do not return goods without receiving a Return Materials Authorization (RMA) number from Munro Products. All returned goods are at the purchasers cost. Opened or used materials will be refused for credit. See all MSDS Sheets which are provided and are also available via our websites.

**Suitability for use:** The user is responsible for establishing that these products are suitable for the user's application and that all requirements for meeting approvals, standards, codes, deposal, use and regulations of any kind are satisfied. Distributor denies any responsibility for establishing suitable of use; where, when, and how the materials from this kit are used. Read all information and instruction before use of this product. Use Caution!

*Tub Refinishing, Inc. DBA Munro Products. BathWorks™ is an exclusive trademark of this company.*

# BATHWORKS

Bathtub Bottom Non-Slip Kit

## NON-SLIP APPLICATION INSTRUCTION MANUAL

**Step 1:** Scrub the desired area thoroughly using the provided Etching Cleaner and water. Dry the area thoroughly.

**Step 2:** Using blue painter's tape, tape a rectangle of desired non-slip area. Non-skid mixture will be applied within these taped lines.

**Step 3:** Using the 120 grit sandpaper, sand the area inside the tape.

**Step 4:** Thoroughly wipe area of all debris.

**Caution:** In the following steps proper ventilation, gloves and eye wear are recommended. Keep all refinishing materials away from children, animals and all those sensitive to fumes.

**Step 5:** With a paper towel or cloth wipe the Liquid Primer onto the non-slip area. Let dry for 5 minutes.

**Step 6:** Pour the entire container of **Hardener** into the **Non-Skid Additive** container. Stir thoroughly.

**Step 7:** Pour the mixture into the center of the desired non-slip area.

**Step 8:** Evenly roll out the material in desired area using the roller.

**Step 9:** Let cure for 24 hours.

**Step 10:** Before first use rinse with cold water.

\*\*\* Dispose of all unused materials and garbage as soon as you have completed the job. Obey all city or town codes for proper paint disposal.