

REFINISHING KIT INSTRUCTION MANUAL

Limited Warranty: Tub Refinishing, Inc. DBA Munro Products or Munro Bath Systems as follows; this warranty is in lieu of all other written or unwritten, expressed or implied warranties, and Tub Refinishing, Inc. DBA Munro Products or Munro Bath Systems expressly disclaims any warranty of merchantability or fitness for a particular purpose. The buyer assumes all risks whatsoever as to the use of the material. Keep away from children, animals, or persons that are sensitive to paint or fumes. Fumes can be harmful to humans and animals, and can also be flammable.

Safety: A protective respirator can be worn if available. Use product with adequate ventilation. Always use rubber gloves.

Tub Refinishing, Inc., DBA Munro Products or Munro Bath Systems, is not responsible for accidents or misuse of these products or parts and materials of this kit. Safety is in the hands of the user. If you are unsure about the use or safety of this product please return the unopened and unused kits to the supplier. Do not return goods without receiving a Return Materials Authorization (RMA) number from Munro Products. All returned goods are at the purchasers cost. Opened or used materials will be refused for credit. See all MSDS Sheets which are provided and are also available via our websites. <http://www.bath tub refinishing kit.net>

Suitability for use: The user is responsible for establishing that these products are suitable for the user's application and that all requirements for meeting approvals, standards, codes, disposal, use and regulations of any kind are satisfied. Distributor denies any responsibility for establishing suitability of use; where, when, and how the materials from this kit are used. Read all information and instruction before use of this product. Use Caution!

For Emergency: CHEMTREC® 1-800-424-9300

Tub Refinishing, Inc. DBA Munro Products, Munro Bath Systems, and BathWorks™. BathWorks™ is an exclusive trademark of this company.

Step 1: Clear the sink of all personal items. Make sure there is positive air-flow as well as good ventilation in work areas at all time.

CLEAN SINK THOROUGHLY! Scrub SINK with Ajax or Comet paying special attention to heavy soap area's. **NOTE:** ANY soap residue left behind will prevent bonding and cause failure.

Step 2: Using either a razor blade or sharp scraper remove the caulk around sink. (optional). Wipe all scrapings and foreign materials into a trash bag that should be next to you at all times for garbage. Never place tools or scraper on toilet seat covers, counter tops or linoleum floors.

Caution: In the following step proper ventilation, gloves, and eye wear are recommended. Sink drains & faucets should be covered UNTIL the rinsing stage of step 3.

Step 3: Pour the entire container of EZ Etch into the center of the sink. With the scotch-bright pad provided thoroughly spread to the entire surface. Let the EZ Etch sit on the desired surface for 20 minutes. Water can be used from the sink or bucket. **Rinse stage:** Rinse well with water & scrubby pad. While the sink is still damp, sand the sink completely using sandpaper provided. Rinse well.

Step 4: Place glove or plastic bag over the sink spout and handles to avoid water dripping on the sink. Using a blow dryer or strong wet-vac, blow water out of drain and handle areas. **NOTE:** Drying the complete surface especially at the drain is extremely important. ANY moisture while rolling will result in failure. When the surfaces are very dry, use blue painters tape to mask off counter around and sink drain. If refinishing both sink and vanity top, you will NOT need to tape off the counter area around the sink.

Step 5: Using a paper towel rub over the full surface cleaning all foreign materials from the sink area. The sink surface should be smooth and ready to be rolled. Any repairs, if needed, should be made to surface before using the paper towel.

Caution: *In the following steps proper ventilation, gloves, and eye wear are recommended. Keep all refinishing kit materials and tools away from children, animals, and anyone sensitive to fumes. Some items in the kit are flammable and should be disposed of properly to city or town codes regulating used paint products. Use all paint products with caution.*

Step 6: With a paper towel wipe the provided liquid primer on the complete sink and/or counter top surface (if refinishing counter top). Dispose of moist paper towel in closed plastic bag (to minimize fumes) when finished. Let the primer dry on the surface for 5 minutes.

Step 7: Thoroughly mix together the provided paint materials - Part A Color (Refinishing Paint) & Part B Hardener. Let mixed paint sit for 5 minutes. Mix thoroughly. You will have roughly 3 to 4 hours to use the product before it becomes unusable. Dispose of unused paint immediately after use. Pour the stirred contents into paint tray provided.

Note: *Never dry roll - the roller should always have a good amount of paint on it.* Next, using the included foam brush, dab-paint around all handles and areas where the roller will not fit. Then, using the included roller, roll the bottom and up the curves of the sink. Remember to use a good amount of paint material while rolling... **this is very important.** Then roll the top edge of sink.

A second coat can be applied right away following the same pattern. Be careful not to lean on wet surfaces. Dispose of all unused materials and garbage, as soon as you have completed the job. Keep away from flames, children, animals and those sensitive to paint fumes; obey all city or town codes for proper paint disposal.

Step 8: Waiting at least 45 minutes after you finish painting, carefully remove the tape. Pull tape at a 45 degree angle when removing. Let painted sink dry 24 hours before using. Once dry, if needed **caulk with 100% Silicone. Allow caulk to dry, and rinse refinished fixture with warm water before using.

Products:

**Bathworks Pro Caulk & Gun in One 100% Silicone Caulk along with Cleaners, and Polishing Kits are available at www.bath-works.net
A good everyday cleaner available in most stores is Scrubbing Bubbles.

Supplies Included in Kit:

Paint Tray & Roller, A & B Paint, 120grit wet/dry Sand Paper, Scrubby Pad, Liquid Primer, Foam Brush, EZ Etch, 4 Rubber Gloves, Directions. **Note:** All SDS can be found at www.bath-works.net

Supplies Needed by Customer: Tarp or Sheet, Blue Painters Tape, Paper Towel, Trash Bag, Razor Blade Scraper, Hair Dryer or Wet-Vac, & Proper Vent or Fan if no window is available. Other protective items you feel necessary under your situation. If unsure, don't paint, and return kit unopened.